
## 1.31 - Felt Underlay Installation

After the plywood has been laid and is sufficiently dry, it is normally covered with 15lb Felt underlay, which is lapped 50mm horizontally and 100mm vertically.

For roof pitches between 9.5 - 15 degrees, a double layer of felf is required. Alternatively a Bitumen Self Adhesive Membrane can be used.

Shingles should not be laid on roof pitches less than 9.5 degrees.



Drawing Name Underlay Installation Guide

1.31 - Underlay Installation Guide.ai

File Name:



Drip Edge

Fig 1.32 - Installing Drip Edges.

installed to create a drip-edge.

All constructions are to comply with New Zealand Building Standards and

Territorial Authority Regulations. The contractor shall verify all dimensions and levels on site before commencing work

These drawings are not to be used for construction without Territorial Authority Consent. Do not attempt to reproduce these drawings in any unlawful manner without the consent of Asphalt Shingle Roofing NZ

Ph: 09 636 7051 | Fax: 09 636 7053 | Free Ph: 0800 261 116 | e-mail: info@asphaltshingle.co.nz www.asphaltshingle.co.nz | PO Box 24 676, Royal Oak, Auckland, New Zealand

These drawings may be utilised in order to create working drawings for submition to a Territorial Authority or certifier for consent purposes.

Sheet 03