



All parapets MUST be capped with metal flashing by the main contractor in accordance with NZBC E2/AS1.

All carpentry works and materials shall be provided by the main contractor.

For roofing underlay & plywood installations, refer to Installation Guide.

Specified cladding by the architect on building wrap on timber frame.



All cladding clearances shall be accordance with manufacturers' specifications.

Stepped Butynol flashing with 150mm upstand behind Building Wrap, installed by ASRNZ. (Refer to Sheet 06 / 1.61 ~ 1.65)

Pabco Asphalt Shingle over felt underlay on 15mm plywood on timber frame.

Felt

ROOF FRAME

	File Name: 2.60 - Parapet to Roof Junction Detail.dwg	Scale: 1:2 @ A4	Drawn By: Sae-woon Lim	Date: 28th January 2007
	Drawing Name: Parapet to Roof Junction Detail			Sheet: 12

All constructions are to comply with New Zealand Building Standards and Territorial Authority Regulations. The contractor shall verify all dimensions and levels on site before commencing work. These drawings are not to be used for construction without Territorial Authority Consent. Do not attempt to reproduce these drawings in any unlawful manner without the consent of Asphalt Shingle Company Limited. These drawings may be utilised in order to create working drawings for submission to a Territorial Authority or certifier for consent purposes.

**Asphalt Shingle Roofing New Zealand**  
 Ph: 09 626 0775 Fax: 09 626 0776 Free Ph: 0800 26 111 6  
 e-mail: info@asphaltshingle.co.nz www.asphaltshingle.co.nz  
 PO Box 24 580, Royal Oak, Auckland, New Zealand